


14.3 Sewer Network

14.3 Sewer Network

The Sewer Network Sub-Module maintains the information regarding the sewer networks of the city.

14.3.1 Navigation to Sewer Network

- Open the sidebar and click on 'Utility IMS' to expand.
- Select the Sewer Network



- This redirect to Sewer Network

Overview:

The Sewer Network Page lists all the attribute records stored in the module and provides different Filters, Actions and Tools that can be used according to the requirements. The For more details (refer to section 5 Filters, section 6 Actions and section 8 Tools).




Figure 14- 10 List of Sewer Network

- The location should be:
 - Middle - if the sewer network is in the middle of the road,
 - Side - if the sewer network is on either the right or left side of the road

Note:

- Deletion of sewer data is not permitted when it is associated with building data.
- Deletion of sewer data is not permitted when it is associated with sewer connection.